

# Installation Instructions


**IMPORTANT:** Fixture(s) must be wired in series! Refer to driver wiring document

Luminaires must be installed by a qualified electrician. Check with local and national codes for proper installation.



To prevent electrical shock disconnect electrical supply before installation or servicing. **Never connect a live fixture!!!** 

Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight. Provide blocking when necessary.



#### **Step 1** Confirm Power Supply is Off!

Unpack luminaire unit. Remote drivers and housings are supplied by Inter-lux.

# Step 2

Ceiling Preparation Mark location, cut opening, and mount J-Box. Pull power (and control) cable(s) inside. Attach Cross Bar with supplied screws.

### Step 3

**Electrical Connection** 

a From fixture, feed cable through Strain Relief and Canopy into J-Box.

**NOTE:** Hex Side of Strain Relief to contact canopy, as shown.

Inside J-Box, connect to power (and control) wire(s) using suitable connectors.

# Step 4

Secure Luminaire Slide Canopy and Strain Relief up suspension cable to the ceiling. Screw Strain Relief to Bar Nut. Lock in place with Set Screw.




#### Included in Box

(1) Fixture Body with Integral Driver (or none, if remote driver specified) with connected cable.

Downlight

Round Cylinder Suspended Cable

- (1) Hex Nut
- (1) Cross Bar
- (2) Cross Bar Screws
- (1) Bar Nut
- (1) Canopy
- (1) Strain Relief with Set Screw



Cross-Section of Fixture

## whitegoods

410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.

